

Food Service Procedure
Calibrating Probe Thermometer

Method Used: Ice Water

Weekly

- Calibrate each thermometer on Friday.
- Or after it has been dropped

Instructions

1. Fill a tumbler with ice.
2. Add water.
3. Place thermometer in cup of ice water.
4. Wait 2 minutes.
5. After 2 minutes, thermometer should read 32. F.

If thermometer does not read 32 F.

1. Leave thermometer in water.
2. Using pliers turn hex nut until needle reads 32 F.
3. Wait 2 minutes.
4. Repeat step 2 if thermometer isn't reading 32 F.

